

# PV Master OPERATION MANUAL

GoodWe Technical Services Center December, 2017 Ver. 1.00

## BRIEF INTRODUCTION

PV Master is an external application for GoodWe inverters to monitor or configure inverters or to do Wi-Fi configuration, used on smart phone or pad for both Android and iOS system, main function of PV Master App as below:

1. Edit system configuration, locally or remotely, to make the system work as it is required
2. Monitor and check performance of both grid-tied and or hybrid systems

*The following pages will introduce the usage of PV Master App on GoodWe hybrid inverters. Any operation on the App for the system please follow this instruction. Any confusion on this introduction, please contact GoodWe for explanation.*



Android System



iOS System

PV Master is used on both iOS and Android system, customers need install this app on your device before using it.

### For Android system:

Download Platform: *Google Play*

Search Keywords: *PV Master / EzViewer*

Compatible System: Android

### For IOS system:

Download Platform: *App Store*

Search Keywords: *PV Master / EzViewer*


Compatible System: *iOS 8.0 or higher version for Iphone/Ipad/Ipod Touch*

## INTERFACE INTRODUCTION

### 1. Home Page Overview


As the App is started up, the first page shows two configuration interfaces as below:

- local configuration (connect smart phone directly to Solar-WiFi \* of the inverter)
- log in for remote monitoring and configuration (after Wi-Fi configuration and registered on GoodWe portal)



If customer had already registered an account, login here use your user name and password (+ and & are not allowed for user name or password)

Here to register an account by email or by phone



Click here to configure inverters by directly connecting Solar-WiFi \*


### 2. Parameters Configuration --- Local Configuration

Local configuration means do inverter configuration by optional two ways:

- Connecting Solar-WiFi\* from inverter directly to your smart phone or pad (pic 1):

**Wi-Fi name:** "Solar-WiFi\*" (\* means the last 8 characters of inverter serial No. )

**Password:** 12345678




- Connect your smart phone to the same network your inverter configured to (after Wi-Fi configuration) refer to Pic 2

Click here to choose the hybrid inverter you want to configure

## Basic Setting

To select Safety Country, Work Mode and Battery Model (all Compulsive settings)



- Click "Login" to enter configuration pages

### → Select "Safety Country"

Please select the right safety country according to the local grid regulations.

- *Scroll up on the page to show more options*
- *If you did not find your local safety country, please select "50Hz Grid Default" or "60Hz Grid Default" according to your local grid frequency*


- After choose the right Safety Country, Click "Next" to select Work Mode for your hybrid inverter



➔ **Select “Work Modes”**

Work Modes decides the automatic operation logic of your hybrid system. So make sure what you select is exactly what you want.

- When you choose any mode, a instruction of the mode you choose will be pop up, as below:



**General Mode:** normally customer use this mode. Solar power firstly support loads, then charge battery, rest power exports to grid, battery will charge or discharge automatically based on the system condition.

**Off-Grid Mode:** used for off-grid condition (without grid access). Choose this mode, **system will automatically cut off grid** connection even though your grid is connected. Click this option will **turn on off-grid charge function** permanently till inverter totally shut down, even though change to another mode.

**Back-Up Mode:** Battery only discharge when grid is unavailable, for urgent use to support back-up loads. Battery charge time set as 00:00-23:59

*Note: battery still possibly charge during 23:59-00:00 each day*

**Economical Mode:** used to set charge/discharge time as customer need, details as below:

- If you choose Economical Mode, it will show options for charge/discharge management (pic 6)  
*Note: Charge/discharge time and power limit only valid when grid is available*

**Charge Manage:** Set a time range and percentage of rated power for battery charge.

**Charge time:** during charge time, battery will not discharge unless grid is unavailable.

**Charge Power Limit:** max charge power ( % of nominal power of the inverter) during charge time


*Eg. for GW3648D-ES, power limit set as 50%, then max charge power of battery from grid will be 50%\*3600W=1800W during charge time*

**Discharge Manage:** Set a time range and percentage of discharge power for battery discharge.

**Discharge time:** during discharge time, battery will always discharge unless grid is unavailable or SOC is low.

**Discharge Power Limit:** max battery discharge power (% of nominal power of the inverter) during discharge time

*Eg. for GW3648D-ES power limit set as 50%, then max discharge power to grid will be 50%\*3600W=1800W during discharge time*




➔ **Select “Battery Type”**

- After set work mode, click “Next” to select battery type (pic 7)

NOTE:

1. For lithium battery, choose wrong battery type will lead to BMS communication failure
2. When choose the battery type, the settings about this battery are all inset, do not have to change



Normally NOT used. This is used only for previous hybrid inverters with lead-acid battery to reset discharge voltage back to default 40V

Used for connecting lithium batteries with BMS communication, which is not in the list with capacity of 50Ah or 100Ah (normally only used for third-party lithium battery communication )


If your battery is not in the list, please choose SELF-DEFINE to set detailed parameters as below

Click “Start” as you choose your battery, basic setting done



There is explanation for each option



Scroll down to check more parameters



NOTE: all the settings must be 100% honest to the battery specifications first

## Advanced Setting

*NOTE: Advanced settings are used special use like "Power Limit" & "Back-Up Function". Normally the password is only for dealers and installers, so please do not tell end users the password if not necessary*



Password:  
goodwe2010

Turn on to use if your grid company does not allow external power feed into grid or customer himself do not want PV production exported to grid


*NOTE: If you use this function and set a Power limit value, then PV production could be limited if consumer or battery charge power is low*


*There is explanation for each option*

Back-Up Supply should always be ON if you have load on Back-Up side (no matter grid is available or not)

Off-Grid Output Switch should be ON **when grid is not available** to access power on Back-Up side

Power Factor: Only used for adjustment when you have reactive power load connected to balance active and reactive power






**Battery Activated:** Used when lithium battery switch off because of low voltage. But for some battery like LG, should switch on battery switch manually first.

**Grid Quality Detection:** only used when customer want system switch to Back-Up mode as grid quality is not good like high grid voltage or bad waveform


**Low Sensitivity:** normally not used. Same function with "Grid Quality Detection" but with lower sensitivity

**Reset Back-Up Overload...:** only used when the system report Back-Up Over Load fault continuously. After decrease Back-Up load to normal range, use this function to start up Back-Up function immediately.

*Click here to choose yes to save advanced settings*



All these functions are same as that in Basic Setting. Normally only for checking.



**Diagnose Message:** If the system works abnormally, customer can click this to check operation condition

**Contact:** Please contact local GoodWe office or [service@goodwe.com](mailto:service@goodwe.com) if you want consult


**Q & A:** Check commonly-asked questions and answers

### 3. Check Parameters of System

- Click "Local Configuration" on the first page to enter configuration page as below:

Note:

- The statues and data on this page might be a few minutes delay from the real-time inverter data
- By touch the icons on the diagram, it will show the real-time data of each part, as below:



The 'Overview' page shows a central diagram with icons for PV, Inverter, On-Grid, Battery, and Load. A hand icon is shown touching the PV icon. The diagram displays power values: 0.00kW for PV, 0.01kW for Inverter, 0.00kW for On-Grid, and 0.00kW for Battery. The status is 'Work Status Normal(Back-up)'.

**Local Configuration** (from the login screen):

- Remember
- Forgot Password?
- Login
- New Registration
- Enter Demo
- Local Configuration

**PV Real-Time Data:**

- PV Voltage / Current / Power
- E-Day & E-Total

**Battery Real-Time Data:**

- Battery Operation Status
- Battery Voltage/Current/Power
- Battery SOC
- BMS Communication Status
- Other BMS information

**Inverter Data:**

- Inverter Serial No.
- Firmware version
- Safety Country
- Inverter Work Status
- Error Messages

**On-Grid Data:**

- Grid Power (V/I/Fout)
- Meter Power (PMeter)
- EzMeter Communication

**Load Data:**

- On-Grid Load Power
- Back-Up Load Power

- Or Click "Param" to check more parameters


Note: the parameters might be different from that on homepage because of refresh time delay and different calculation formula

**Battery Status:** showing real-time battery SOC and work status including "Charge" or "Discharge"

**BMS Status:** showing real-time BMS communication status of lithium battery ("Communication OK" means normal)

**SOH:** BMS send out this info, showing the health status of lithium battery - 100% means perfectly healthy

**Charge/Discharge Current Limit:** showing the real-time limitation on battery charge/discharge - this determines the real allowed charge/discharge current for Lithium battery.



The 'Param' page displays the following data:

System Data	
PV Input	0.0V/0.0V 0.0A/0.1A
On-Grid Output	223.3V/0.0A/0.00kW
Back-Up Output	231.1V/0.00kW
Import Power	NA


  

Battery (GCL 5.6kWh)	
Battery status	SOC:14, Discharge
V/I/W	51.1V/0.3A/0.02kW
BMS Status	Communication OK
SOH(From BMS)	100%
Charge Current Limit(From BMS)	23A
Discharge Current Limit(From BMS)	23A
Warning(From BMS)	Normal
Temperature(From BMS)	25.0kWh

## 4. Auto-Test (for Italy only)

Note:

- Auto-test option only accessible when you choose "Italy" as safety country
- Before use Auto-Test, make sure Solar-WiFi signal is connected on your smart phone stably



### ● Auto-Test Operation Process

- Click Auto-Test ,then inverter will be under auto-test mode
- Connect AC, the inverter shows on-grid successfully, and output power is zero.
- Under normal communication condition, the inverter SN, model, firmware version and safety country (If it's not Italy, please change it to Italy) will be obtained automatically

Note:

- "Remote" default set is 1, unable to be modified
- "Local" default set is 0, which can be set to 0 or 1.

- If no setting "Remote" and "Local", then test with the default value.

Testing in order : 59.S1, 59.S2, 27.S1, 81>S2, 81<S2

NOTE: If set "Local" to 1, then testing order would be 59.S1, 59.S2, 27.S1, 81>S2,81<S2

- If sub test finishes and shows Pass, inverter relay breaks off and reconnect to grid automatically according to CEI 0-21 requirement. Then start the next testing.

NOTE:

- After passing Auto-test, testing data will be stored in the album, for future reference.
- If you quit the test or exit testing screen halfway, test will be terminated.

### WARNING:


- Make sure your smart phone keeps unlocked during Auto-Test, or, the test will stop and fail
- If the test fails during Auto-Test, inverter will enter wait mode. Will need reconnect Solar-WiFi\* to finish the test or totally power inverter and reboot to try again.

## 5. Wi-Fi Configuration


A successful Wi-Fi configuration is necessary for remote monitoring, configuration and after-sales maintenance and control.

→ Enter Wi-Fi Configuration page: there are two ways for access to Wi-Fi Configuration

a. **Before Log in:** *Local Configuration* → *Set* → *Configure Wi-Fi Quickly* as below:





b. **Login your account or enter Demo account:** see below:



Where the sun shines there is GoodWe

→ Wi-Fi Configuration Process:

**Step 1:** Make sure your inverter is powered and Solar-WiFi signal is connected on your smart phone




Choose your network here


Fill in password of your network

**Step 2:** Click "Next" to choose your network or input network name and password

**Step 3:** As you choose/input network name and password, press "Start" to start connection



Input your network and password manually



Any problem on Wi-Fi configuration, please find here trouble shootings

**Step 4:** As the page shows success, then click "OK" to finish configuration process


**NOTE:**

1. After configuration, normally the Wi-Fi or Power led on inverter will change from double blink to quartic blink then burning after around 10 seconds
2. The configuration process might still finish even password of your network is wrong, so make sure the password you input is absolutely right.

## 6. Account register and build station for your advices

On PV Master APP, you can register an account via E-mail or cell phone No. for monitoring and remote control.

### → Register an Account



GOODWE  
your solar engine

Fill in Phone/User name/Email

Password


Remember      Forgot Password?

Login

New Registration

Enter Demo    Local Configuration

Copyright© 2016 GoodWe V2.1.0



New Registration

Register by Phone    Register via Email

Select User Type

China    +86


Please Input Phone    Send Code

Please Input Code

Password

Registration

As input your phone No. click here to receive a checksum code by SMS



New Registration

Register by Phone    Register by Email

Select User Type

Please Enter The Email

Password

Registration

End User

Dealer/Installer

Cancel



*Please carefully choose your user type.  
If you are an installer, please contact your distributor for a dealer code*

*If you are a dealer, direct distributor of GoodWe, then please contact GoodWe sales for dealer code*


**NOTE:** Each E-mail address or cell phone No. can register only one account

→ **Build station and register device in it**


Step1: Log in your account



Click here to add new station for your devices, by scanning serial No. bar code




Or input inverter serial No. and check code manually



Click here after input serial No. and check code

Last step: Click to save the station

Station name is a "MUST" information




Station location will be located automatically where you use the phone to build station

## 7. Remote Configuration and Monitoring

Remote configuration and monitoring is **only accessible for dealer account** after Wi-Fi configuration successfully and build station on PV Master App or GoodWe portal.

### ➔ Remote Configuration



**Step 1: Login**

goodwe\*\*  
\*\*\*\*\*  
 Remember  Forgot Password?  
Login

**Step 2: Station Overview**

All Stations

- 9  
kW/kWp: 0.000kW  
EDay: 0.0kWh  
EquivalentHour: 0.00  
Power: 0.000kW  
ETotal: 0.0kWh  
CreateTime: 2017-10-25
- 固德威4号  
kW/kWp: 0.000kW  
EDay: 0.0kWh  
EquivalentHour: 0.00
- 666666  
kW/kWp: 0.000kW  
EDay: 0.0kWh

**Step 3: Device Configuration**

15080BPS19E00140

15080BPS19E00140  
Power:0W  
Status:offline  
EDay:0.0kWh  
ETotal:0.0kWh  
Error:N/A

Configure

输入电压:  
并网输入:  
Back-up输出:  
买/卖电功率:  
电池状态:  
电压/电流/功率:  
BMS信息:  
健康状况(来自BMS):  
充电限流(来自BMS):  
放电限流(来自BMS):  
电池警告(来自BMS):  
固件版本:  
安规国家:  
工作状态:  
错误信息1:  
错误信息2:  
错误信息3:

95048ESU17200223  
Power:0W  
Status:offline  
EDay:0.0kWh

Home Chart Device List

**Step 4: Clouds Settings**

Country: Italy >  
Select your country or standard.

Battery Type: Self-Define >  
Select the battery model, different model has different parameters

Battery Capacity: 0 Ah  
Set the closest value to the sum of whole battery package

Select work mode

- General Mode: Self-use First
- Off-Grid Mode: Grid is Unavailable
- Back-up Mode: Battery ONLY for Back-up Use.
- Economical Mode: More Interaction with Grid.

Electricity Price vs Time graph

**Step 5: Discharge Depth**


Discharge Depth

Namely DOD, means the max percentage of battery power capacity allowed to discharge. Only effective when SOC Protection is turned ON

Send

Where the sun shines there is GoodWe

→ Remote Monitoring



**Step 1: Login your account**

**Step 2: Click the station you want check**


**Step 3: Click here to choose the inverter you want check**

In the monitoring page, you can check data as below:


Overall real-time performance



Daily performance



Monthly / Yearly performance





Inverter location




## 8. User Center


User center is a self-designable page to create your own style




Click to log out your account



Check the warranty of your inverter



The message you select will be pushed on your phone



Operational input of calculated profit per kWh